

## Control Panels

## Option Availability 50Hz

### Midi Only

RANGE	BC 701E-M	BC 701-M	BC 704E-M	BC 704-M	BC 5110E-M	BC 5110-M	BC 5310-M
<b>'Midi' Range</b>							
Mitsubishi	●	○	○	○	○	○	○

● Standard Equipment    ○ Available as an Option

### All Other Models

RANGE	BC 701	BC 704	BC 5110	BC 5310	BC 5320	BC 5510	BC 5520
<b>John Deere</b>							
BCJD 330-50 to 440-50 BCJD 88-50 E2 to BCJD 500-50 E2 * BCJD 60-50SP E2 to BCJD 74-50SP E2				●	○	○	○
BCJD 44-50 to 275-50 BCJD 30-50SP to 74-50SP BCJD 33-50 E2 to 64-50 E2 BCJD 16-50SP E2 to 45-50SP E2	●	○	○	○	○	○	○
<b>Volvo</b>							
All BCV models. *				●	○	○	○
<b>Deutz</b>							
All BCD models	●	○	○	○	○	○	○
<b>Cummins</b>							
All BCC models.			●	○	○	○	○
<b>Mitsubishi</b>							
All BCM models.			●	○	○	○	○
<b>Perkins</b>							
All BCP models			●	○	○	○	○

\* SAE J1939 CANBus Interface

● Standard Equipment    ○ Available as an Option